

ŠKODA Wallbox

LED Controls – Common usage

SKODA
eMobility



The charger is switched on

You can start a charging session by connecting your car and authorizing the charging process.



Authentication required

If the upper icon flashes white, use your charging card or the app for authentication.



Authentication successful

If the upper icon flashes green, authentication via the charging card or app was successful.



The charger establishes a connection (starts up)

The charger establishes a connection or waits for an ongoing process to end.



Charging session in progress

If the green line moves from the house icon to the vehicle icon, your car is being charged.



The charging session is paused

If the central LED flashes green, the charging session has been interrupted. The charging session will resume automatically, e.g., when sufficient energy is available or at the beginning of a charging schedule.



Fully charged

As soon as your car is fully charged, the entire LED bar lights up green.



Software update is being carried out

If the entire LED bar flashes yellow, the charger software is being updated. The status changes once the update is complete.

ŠKODA Wallbox

LED Controls – Faults and configuration

SKODA
eMobility



Authentication rejected

If the upper icon flashes red five times, authentication via the charging card or app was not successful.



Configuration required

If the central LED flashes blue, the charger must be configured via the mobile or web app.



Faulty RFID module

The charger has detected an error in the RFID module. Contact Customer Support.



Critical error (house)

If the LED below the house icon flashes orange, the charger has detected a problem with the connection to your home's electrical connection.



Critical error (charger)

If the LED below the energy icon flashes orange, the system has detected a problem with the charger.



Critical error (car)

If the LED below the car icon flashes orange, the charger has detected a problem with your car



Fatal error

If the RFID symbol flashes red and the entire LED strip lights up red, the charger has detected a fatal error. Contact Customer Support.



SKODA